

Laptop studio 1555 do not start: No display

Posted by admin - 26 Jun 2012 08:10

This is no display on My laptop. The display goes off after single blink when i press the on/off button.

Please help to resolve at the earliest.

=====